2020 MY All Vehicles – Federal/California Specifications Vehicles

MAINTENANCE ITEM		MAINTENANCE INTERVAL (Number of months or km (mi), whichever occurs first)																							
		Months x 1,000 km x 1,000 mi	6 9.6 6	12 19.2 12	18 28.8 18	24 38.4 24	30 48.0 30	36 57.6 36	42 67.2 42	48 76.8 48	54 86.4 54	60 96.0 60	66 105.6 66	72 115.2 72	78 124.8 78	84 134.4 84	90 144.0 90	96 153.6 96	102 163.2 102	108 172.8 108	114 182.4 114	120 192.0 120	126 201.6 126	132 211.0 132	REMARKS
1	Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1
2	Engine oil filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	Note 1
3	Spark plug											R										R			
4	Drive belt(s)						I					I					I					I			
5	Timing belt (WRX STI)																R								
6	Fuel systems, lines & connections						I					I					I					I			Note 6 & 7
7	Fuel filter													R											Note 2 & 7
8	Air cleaner element						R					R					R					R			Note 8
9	Cooling system, hoses & connections						I					I					I					I			Note 10
10	Engine coolant (engine side), (inverter assembly side - Hybrid)		Replace after the first 11 years or 220,000 km (137,500 miles), and every six years or 120,000 km (75,000 miles) thereafter.																						Note 10
11	Clutch operation			I		I		I		I		I		I		I		I		I		I		I	
12	Transmission gear oil (except BRZ)						I					I					I					I			Note 3
	Transmission gear oil (BRZ)					I				I				I				I				I			
13	CVT fluid (except BRZ & Hybrid)							I					I					I					I		Note 4
	ATF (BRZ & Hybrid)							I					R					I					R		
14	Front & rear differential gear oil (except BRZ)						I					I					I					I			Note 3
	Rear differential gear oil (BRZ)			I		I		I		I		I		I		I		I		I		I		I	
			Replace every 4 years or 96,000 km (60,000 miles).																						
15	Brake lines, operation of parking & service brake systems			I		I		I		I		I		I		I		I		I		I		I	Note 6
16	Brake fluid / clutch fluid (MT only)						R					R					R					R			Note 5
17	Disc brake pad & disc, front & rear axle boots & joints			I		I		I		I		I		I		I		I		I		I		I	Note 6
18	Steering & suspension			I		I		I		I		I		I		I		I		I		I		I	Note 6
19	Wheel bearing											I										I			
20	Rotate & inspect tires		P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	Note 9
21	HVAC system A/C filter			R		R		R		R		R		R		R		R		R		R		R	Note 8

R=Replace. I=Inspect, correct or replace if necessary. P=Perform.

4357303_20c_Subaru_Warranty_and_Maintenance_guts_020720.indd 28 2/7/20 9:05 AM